

Chemical Vulcanizing Cement Instructions



These instructions apply to cold vulcanizing cement.
They do not apply to 14-515 or 14-516.

For more information call 1.800.438.3302
For SDS Information Visit www.31inc.com

Directions

1. **CLEAN** thoroughly a large area around the injury using Rubber Prep. (14-100, 14-102, 14-103, 14-490)
2. **BUFF** prepared repair area to a velvety smooth RMA #1 texture.
3. **CEMENT** prepared area. Work well into rubber with stippling action making sure not to puddle. Allow the cement to dry completely. (Approx. 3-5 minutes depending on temperature / humidity)
4. **APPLY REPAIR UNIT** according to instructions for the repair material to be used.

For more information,
call (800) 438-3302.

REV 03.07.2016