



These instructions apply to all 31Inc Inner-Liner Sealer.

For more information call 1.800.438.3302 For SDS Information Visit www.31inc.com

Directions

Apply **AFTER** repair is complete. Shake can well. Apply a light coat around edge of repair and at least 2" beyond repair. Be sure to cover all buffed areas of the inner-liner. Allow 5 minutes drying time.

When installing repair units in agricultural tires that will contain calcium, coat the entire repair unit with inner-liner sealer after installation.

For more information, call (800) 438-3302.

REV 03.07.2016