

MOUNT & DEMOUNT SOLUTIONS

Xtra seal

PROFESSIONAL TIRE REPAIR



14-700
6 1/2LB
WHITE

TIREPASTE™



14-701
11LB
WHITE

TIREPASTE™



14-699
6 1/2LB
WHITE
LOW PROFILE

TIREPASTE™



14-705
6 1/2LB
BLUE

PREMIUM TIREPASTE™



14-706
11LB
BLUE

PREMIUM TIREPASTE™



14-753
1 GALLON
CONCENTRATE

X-TRA SLIK BEAD LUBE



14-753PM
1 GALLON
CONCENTRATE

X-TRA SLIK BEAD LUBE



14-378

Tire Swab
11" Cotton



14-378L

Tire Swab
15" Cotton



TIRE SWABS & BRUSHES



14-713

**Soft Bristle Tire Paste
Applicator Brush**
2" Diameter



14-712

**Soft Bristle Tire Paste
Applicator Brush**
1 1/2" Diameter



14-711

**Tire Paste
Applicator Brush**
1" Diameter

TIRE & WHEEL SERVICE

Xtra seal

PROFESSIONAL TIRE REPAIR

WHEEL BALANCING

16-301

CounterAct
1oz Balancing Bead
40 Per Case



16-302

CounterAct
2oz Balancing Bead
32 Per Case



16-303

CounterAct
3oz Balancing Bead
24 Per Case



16-304

CounterAct
4oz Balancing Bead
92 Per Case



16-305

CounterAct
5oz Balancing Bead
76 Per Case



16-306

CounterAct
6oz Balancing Bead
64 Per Case



16-308

CounterAct
8oz Balancing Bead
52 Per Case



16-310

CounterAct
10oz Balancing Bead
40 Per Case



16-312

CounterAct
12oz Balancing Bead
36 Per Case



16-314

CounterAct
14oz Balancing Bead
32 Per Case



16-316

CounterAct
16oz Balancing Bead
28 Per Case



HOW IT WORKS!

The beads are distributed around the tire as it begins to roll, through centrifugal force.

As the centrifugal force increases, the heavy spot pulls up and down on the suspension, making the beads move in the opposite direction of the downward and upward motion, through inertia.

The beads continue to migrate until the complete wheel assembly is balanced.



TIRE REPAIR BASICS



14-008
Vulcanizing
Cement

8 oz



14-100
Rubber Prep

32 oz



14-101
Bead Sealer

32 oz



31inc.com
740.498.8324
800.438.3302

100 Enterprise Dr.
Newcomerstown, OH 43832